

Pioneer


DIGITAL MEDIA RDS/Bluetooth RECEIVER
RECEPTOR DE MEDIOS DIGITALES Con RDS/Bluetooth
DIGITAL MEDIA PLAYER con RDS/Bluetooth

MVH-X3000BT MVH-S325BT

Quick start guide Guía de inicio rápido Guía de Inicio Rapido

QRD3782-B

Basic operation



Basic operation

1 Press the **M.C.** dial to display the main menu.

2 Turn the **M.C.** dial to select one of the categories below, then press to confirm.

- FUNCTION settings
- AUDIO settings
- SYSTEM settings
- ILLUMINATION settings
- MIXTRAX settings
- MICROPHONE settings (only for MVH-X3000BT)

3 Turn the **M.C.** dial to select the options, then press to confirm.

This guide is intended to guide you through the basic functions of this unit. For details, please refer to the Operation manual stored on the website. <http://www.pioneer-latin.com/en/support/operating-manuals/>

Before You Start

Thank you for purchasing this PIONEER product. To ensure proper use, please read through this guide before using this product. It is especially important that you read and observe **WARNING** and **CAUTION** in this guide. Please keep the guide in a safe and accessible place for future reference.

WARNING

- Do not attempt to use this service this product by yourself. Installation or servicing of this product by persons without training and experience in electronic equipment and automotive accessories may be dangerous and could expose you to the risk of electric shock, injury or other hazards.
- Do not attempt to operate the unit while driving. Make sure to pull off the road and park your vehicle in a safe location before attempting to use the controls on the device.

CAUTION

- Do not allow this unit to come into contact with moisture and/or liquids. Electrical shock could result. Also, damage to this unit, smoke, and overheating could result from contact with liquids.
- Always keep the volume low enough to hear outside sounds.
- This product is evaluated in moderate and tropical climate condition under the Audio, video and similar electronic apparatus - Safety requirements, IEC 60065.

The operation of this unit is subject to the following conditions:

- It is possible that this unit or device doesn't cause harmful interference and 2) this unit must accept any interference, including the interference that may cause undesired operation.

If you experience problems

Should this unit fail to work properly, please contact your dealer or nearest authorized PIONEER Service Station.

Important

- When installing this unit in a vehicle without an ACC (accessory) position on the ignition switch, failure to connect the red cable to the terminal that detects operation of the ignition key may result in battery drain.

ACC position **No ACC position**

- Use this unit with a 12-volt battery and negative grounding only. Failure to do so may result in a fire or malfunction.

About the main menu

You can adjust various settings in the main menu.

1 Press the **M.C.** dial to display the main menu.

2 Turn the **M.C.** dial to select one of the categories below, then press to confirm.

- FUNCTION settings
- AUDIO settings
- SYSTEM settings
- ILLUMINATION settings
- MIXTRAX settings
- MICROPHONE settings (only for MVH-X3000BT)

3 Turn the **M.C.** dial to select the options, then press to confirm.

Frequently used operations

Purpose	Operation
Turn on the power	Press SRC/OFF to turn on the power. Press and hold SRC/OFF to turn off the power.
Adjust the volume	Turn the M.C. dial.
Select a source	Press SRC/OFF repeatedly.
Change the display information	Press DISP/DISP repeatedly. Press and hold DISP/DISP OFF to turn off the display information.
Return to the previous display/list	Press BAND/ .
Return to the normal display from the menu	Press and hold BAND/ .
Change the display brightness	Press and hold BAND/ .

Connections

WARNING

- When speaker output is used by 4 channels, use speakers rated over 50 W (maximum input power) and between 4 Ω to 16 Ω (impedance value). Do not use 1 Ω to 3 Ω speakers for this unit.
- When rear speaker output is used by a 2 Ω subwoofer, use speakers rated for over 70 W.
- Please refer to connections for a connection method.

The black cable is ground. When installing this unit or power amp (sold separately), make sure to connect the ground wire first. Ensure that the ground wire is properly connected to metal parts of the car's body. The ground wire of the power amp and the one of this unit or any other device must be connected to the car separately with different wires. If the screw for the ground wire loosens or falls out, it could result in fire, generation of smoke or malfunction.


Two devices connected to the car separately (ground wire).

Important

- When installing this unit in a vehicle without an ACC (accessory) position on the ignition switch, failure to connect the red cable to the terminal that detects operation of the ignition key may result in battery drain.

ACC position **No ACC position**

- Use this unit with a 12-volt battery and negative grounding only. Failure to do so may result in a fire or malfunction.



Boost the bass level (Club Sound Bass)	Press and hold MIX. (MVH-X3000BT) Press BASS. (MVH-S325BT) • You can select the bass level ([HI] or [LOW]) in [D.BASS].
Turn MIXTRAX on/off	Press MIX.

Setup operation



When you turn the ignition switch to ON after installation, the setup menu appears in the display.

1 Turn the **M.C.** dial to select the options, then press to confirm.

To proceed to the next menu option, you need to confirm your selection.



Menu Item	Description
LANGUAGE ([ENG](English), [ESP](Spanish))	Select the language to display the text information from a compressed audio file.
CLOCK SET	Set the clock. 1 Turn the M.C. dial to adjust the hour, then press to confirm. The indicator moves to the minute setting automatically. 2 Turn the M.C. dial to adjust the minute, then press to confirm.
FM STEP [100], [50]	Select the FM tuning step from 100 kHz or 50 kHz.
AM STEP [10], [9]	Select the AM tuning step from 10 kHz or 9 kHz.

This unit





* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.


Power cord



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.

USB/iPhone/AUX operation

(iPhone source is not available when USB MTP) is set to [ON] in the SYSTEM settings.)

USB/iPhone

- Open the USB port cover.
- Plug in the USB device/iPhone using an appropriate cable.

MTP connection

A device installed with Android OS 4.0 or most of later versions can be connected to the unit via MTP, using the cable supplied with the device. However, depending on the connected device, OS version or the numbers of the files in the device, audio files/songs may not be able to be played back via MTP.

NOTE

If you use an MTP connection, [USB MTP] needs to be set to [ON] in the SYSTEM settings.

AUX

- Insert the stereo mini plug into the AUX input jack.
- Press **SRC/OFF** to select [AUX IN] as the source.


Activating voice recognition mode

- Press and hold **VOICE** and then talk into the microphone to input voice commands.


Installation

Important

- Check the connections and systems before final installation.
- Do not use unauthorized parts as this may cause malfunction.
- Consult your dealer if installation requires drilling of holes or other modifications to the vehicle.
- Do not install this unit where:
 - It may interfere with operation of the vehicle.
 - It may cause injury to a passenger as a result of a sudden stop.
- Install this unit away from hot places such as near the heater outlet.
- Optimum performance is obtained when the unit is installed at an angle of less than 60°.
- When installing, to ensure proper heat dissipation, when using this unit, make sure you leave ample space for the rear panel and wrap any loose cables so they are not blocking the vents.



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.

Bluetooth connection

Up to two Bluetooth telephones can be connected simultaneously.

- Turn on the Bluetooth function of the device.
- Select the unit name shown in the device display.
- Make sure the same 6-digit number appears on this unit and the device.
- Select [YES].

Bluetooth telephone

Purpose	Operation
Answer an incoming call	Press any button when a call is received.
End a call	Press END .
Reject an incoming call	Press and hold END when a call is received.

Activating voice recognition mode

- Press and hold **VOICE** and then talk into the microphone to input voice commands.

To exit the voice recognition mode, press **BAND/**.

Installing the microphone

The microphone should be placed directly in front of the driver at a suitable distance to pick up the voice clearly.

CAUTION

It is extremely dangerous to allow the microphone lead to become wound around the steering column or shift lever. Be sure to install the microphone in such a way that it will not obstruct driving. It is recommended to use the clamps (sold separately) to arrange the lead.

NOTE

Depending on the vehicle model, the microphone cable length may be too short when you mount the microphone on the sun visor. In such cases, install the microphone on the steering column.

To install on the sun visor

- Fit the microphone lead into the groove.



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.

Making a connection with Pioneer Smart Sync

Pioneer Smart Sync is the application that intelligently brings your maps, messages, and music together in the vehicle.



WARNING

Do not attempt to operate the application while driving. Make sure to pull off the road and park your vehicle in a safe location before attempting to use the controls on the application.

- Enter the SYSTEM menu (refer to "About the main menu").
- Turn the **M.C.** dial to select [APP CONTROL], then press to confirm.
- Turn the **M.C.** dial to select one of the below.
 - Select [WIRED] for the USB connection.
 - Select [BLUETOOTH] for the Bluetooth connection.
- Turn the **M.C.** dial to select [ON], then press to confirm.


6 Connect this unit with the mobile device via USB or Bluetooth. Pioneer Smart Sync on the iPhone/Android device starts automatically.

Adjusting the microphone angle

The microphone angle can be adjusted.

To install on the steering column


- Detach the microphone base from the microphone clip by sliding the microphone base while pressing the tab.



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.

NOTE

Regardless of whether the [AUTO APP CONN] setting is set to [ON] or [OFF], you can also perform the following to start Pioneer Smart Sync.

- For devices other than the USB-connected Android device, press **SRC/OFF** to select any source and press and hold the **M.C.** dial.
- For iPhone, launch Pioneer Smart Sync on the mobile device.

Listening to Spotify*

(Not available when USB MTP) is set to [ON] in the SYSTEM settings.)

Update the firmware of the Spotify application to the latest version before use.

Before you start, connect this unit with the mobile device via USB (iPhone only) or Bluetooth.

- Enter the SYSTEM menu (refer to "About the main menu").
- Turn the **M.C.** dial to select [APP CONTROL], then press to confirm.
- Turn the **M.C.** dial to select one of the below.
 - Select [WIRED] for the USB connection.
 - Select [BLUETOOTH] for the Bluetooth connection.
- Press **SRC/OFF** to select [SPOTIFY].

5 Launch the Spotify application on the mobile device and start playback.

Spanish

Esta guía tiene la intención de guiarlo a través de las funciones básicas de esta unidad.

Para más detalles, consulte el manual de operación que se almacena en este sitio web.

<http://www.pioneer-latin.com/es/soparte/manuales-usuario/>

Antes de comenzar

Gracias por adquirir este producto PIONEER.

Para asegurar un uso correcto, lea este manual por completo antes de usar el producto. Es de especial importancia que lea y cumpla con las **ADVERTENCIAS** y **PRECAUCIONES** de este manual. Conserve el manual en un lugar seguro y de fácil acceso para consultarlo en el futuro.

ADVERTENCIA

No trate de instalar o reparar este producto usted mismo. La instalación o la reparación de este producto por parte de personas sin cualificación ni experiencia en equipo electrónico y accesorios para automóviles puede ser peligrosa y puede exponerle al riesgo de sufrir una descarga eléctrica u otros peligros.

No intente utilizar la unidad mientras está conduciendo. Asegúrese de salir de la carretera y aparcar su vehículo en un lugar seguro antes de intentar utilizar los controles del dispositivo.

PRECAUCIÓN

No permita que esta unidad entre en contacto con humedad ni líquidos. Puede sufrir un choque eléctrico. Además, el contacto con líquidos puede provocar daños en la unidad, humo o sobrecalentamiento.

Mantenga siempre el volumen lo suficientemente bajo como para escuchar los sonidos que provienen del exterior.

Este producto es evaluado en condiciones de clima moderado y transportado en aparatos electrónicos de audio, video y similares. Requisitos de seguridad, IEC 60065.

La operación de este equipo está sujeta a las siguientes dos condiciones:

1) Es posible que este equipo o dispositivo no cause interferencia perjudicial y 2) este equipo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

En caso de problemas con el dispositivo

Si esta unidad no funciona correctamente, póngase en contacto con su concesionario o con el centro de servicio PIONEER autorizado más cercano.

Conexiones

Utilice esta unidad con una batería de 12 voltios y conector a tierra negativa únicamente. En caso contrario, se podría producir un incendio o un mal funcionamiento.


Para evitar un cortocircuito, sobrecalentamiento o un mal funcionamiento, asegúrese de seguir las indicaciones siguientes:

- Desconecte el terminal negativo de la batería antes de la conexión.
- Asegure el cableado con pinzas para cable o cinta adhesiva. Envuelva la cinta adhesiva alrededor del cableado que está en contacto con las partes metálicas para proteger el cableado.
- Coloque todos los cables lejos de las piezas móviles, como la palanca de cambios y los rieles de los asientos.
- No pase el cable amarillo por el orificio del compartimento del motor para conectarlo a la batería.
- Cubra los conectores de los cables desconectados con cinta aisladora.
- No acorte ningún cable.
- Nunca corte el aislamiento del cable de alimentación de esta unidad para comprobar la alimentación con otros dispositivos. La capacidad actual del cable es limitada.
- Evite un cortocircuito de la batería.
- Nunca conecte el cable negativo del altavoz directamente a la tierra.
- Nunca use cinta para unir los cables negativos de varios altavoces.
- Si esta unidad está encendida, las señales de control se envían a través del cable azul.
- Si el vehículo está equipado con una antena en el parabrisas, conecte el terminal de alimentación del amplificador de la antena.
- Nunca conecte el cable azul/blanco al terminal de alimentación de un amplificador de potencia externo. Además, nunca lo conecte al terminal de alimentación de la antena automática. De lo contrario, es posible que la batería se agote o se produzca un mal funcionamiento.
- El símbolo gráfico  se encuentra en el producto significa corriente continua.

* No se suministra para esta unidad.


Importante

- Al instalar esta unidad en un vehículo sin posición ACC (accesorio) en la llave de encendido, si no se conecta el cable rojo al terminal que detecta la operación de la llave de encendido, es posible que se agote la batería.




* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.

Esta unidad




* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

Cable de alimentación



* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.




* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

Instalación

Importante

- Compruebe todas las conexiones y los sistemas antes de la instalación final.
- No utilice piezas ni antenas, ya que pueden causar un mal funcionamiento.
- Consulte con su concesionario si la instalación puede provocar daños a otros componentes en el vehículo.
- No instale esta unidad donde:
 - pueda interferir con el funcionamiento del vehículo.
 - pueda causar lesiones a un pasajero como resultado de una frenada repentina.
- Instale esta unidad lejos de lugares calientes, como cerca de la salida de la calefacción.
- Se logra un rendimiento óptimo cuando la unidad se instala con un ángulo de menos de 60°.
- Cuando se lleve a cabo la instalación, asegure la correcta disposición del calor al utilizar este producto, asegúrese de dejar un espacio amplio detrás del panel trasero y envolver los cables sueltos para que no obstruyan las aberturas de ventilación.




* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.

Instalación del montaje DIN

1 Inserte el manguito de montaje suministrado en el tablero.

2 Asegure el manguito de montaje con un destornillador para doblar las patillas metálicas (90°) hasta su lugar.



* The ignition and caller's voice of the Bluetooth telephone are not output from the rear speakers.

Conexión Bluetooth

Se pueden conectar hasta dos teléfonos Bluetooth a la vez.

- Active la función Bluetooth del dispositivo.

2 Seleccione el nombre de la unidad que aparece en la pantalla del dispositivo.

3 Asegúrese de que el mismo número de 6 cifras aparezca en esta unidad y el dispositivo.

4 Seleccione [YES].

Teléfono Bluetooth

Funcionamiento básico

Objetivo	Funcionamiento
Responder una llamada entrante	Mantenga presionado cualquier botón cuando reciba una llamada.
Finalizar una llamada	Presione END .
Rechazar una llamada entrante	Mantenga presionado END cuando reciba una llamada.

Activación del modo de reconocimiento por voz

- Mantenga presionado **VOICE** y hable al micrófono para dar los comandos de voz.

Para salir del modo de reconocimiento de voz, presione **BAND/**.

Funcionamiento de la configuración

Después de la instalación, gire la llave de encendido hasta la posición ON y aparecerá el menú de configuración en la pantalla.

1 Gire el dial **M.C.** para seleccionar las opciones y presione para confirmar.

Para avanzar a la siguiente opción de menú, debe confirmar la selección.

Volver a la visualización normal desde el menú	Mantenga presionado BAND/ .
Cambiar el brillo de la pantalla	Mantenga presionado BAND/ .
Intensificar el nivel de graves (Club Sound Bass)	Mantenga presionado MIX. (MVH-X3000BT) Presione BASS. (MVH-S325BT)
• Puede seleccionar el nivel de graves ([HI] o [LOW]) en [D.BASS].	
Encender o apagar MIXTRAX	Presione MIX.

Funcionamiento de la configuración

Después de la instalación, gire la llave de encendido hasta la posición ON y aparecerá el menú de configuración en la pantalla.

1 Gire el dial **M.C.** para seleccionar las opciones y presione para confirmar.

Para avanzar a la siguiente opción de menú, debe confirmar la selección.

Elemento del menú	Descripción
LANGUAGE ([ENG](Inglés), [ESP](Español))	Seleccione el idioma en el que aparecerá la información de texto de un archivo de audio comprimido.
CLOCK SET	Ajuste el reloj. 1 Gire el dial M.C. para ajustar la hora y presione para confirmar. El indicador se mueve al ajuste de minutos automáticamente.
	2 Gire el dial M.C. para ajustar los minutos y presione para confirmar.

* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

* El tono de llamada y la voz del interlocutor del teléfono Bluetooth no se emiten desde los altavoces traseros.

Funcionamiento de la configuración

Después de la instalación, gire la llave de encendido hasta la posición ON y aparecerá el menú de configuración en la pantalla.

1 Gire el dial **M.C.** para seleccionar las opciones y presione para confirmar.

Para avanzar a la siguiente opción de menú, debe confirmar la selección.

Volver a la visualización normal desde el menú	Mantenga presionado BAND/ .
Cambiar el brillo de la pantalla	Mantenga presionado BAND/ .
Intensificar el nivel de graves (Club Sound Bass)	Mantenga presionado MIX. (MVH-X3000BT) Presione BASS. (MVH-S325BT)
• Puede seleccionar el nivel de graves ([HI] o [LOW]) en [D.BASS].	
Encender o apagar MIXTRAX	Presione MIX.

Funcionamiento de la configuración

Des

